

Manual

Interface modules

The logo consists of the letters 'W&T' in a bold, white, sans-serif font, centered within a solid black rectangular box.

| | |
|-------|---|
| Model | 18801, 18811 18802, 18812 18803, 18813 18601, 18611 18602, 18612 18401, 18411 18402, 18412 18101, 18111 18120, 18121 18311 |
|-------|---|

| | |
|---------|-----|
| Version | 1.3 |
|---------|-----|

© 08/2005 by Wiesemann und Theis GmbH

Subject to error and alteration:

Since it is possible that we make mistakes, you mustn't use any of our statements without verification. Please, inform us of any error or misunderstanding you come about, so we can identify and eliminate it as soon as possible.

Carry out your work on or with W&T products only to the extent that they are described here and after you have completely read and understood the manual or guide. We are not liable for unauthorized repairs or tampering. When in doubt, check first with us or with your dealer.

The modular design of all W&T Com-Servers as well as most of the W&T PC cards allows them to be equipped with various serial interface types.

Modification of the standard units is accomplished by simply exchanging the existing interface modules with modules of the desired interface type.

The W&T interface module family is described on the following pages along with the corresponding technical data and including connection examples.

For up-to-date information on new developments, see our Internet site at <http://www.wut.de> or check the e-mail short notices at the W&T Interface Club, which you can also subscribe to from the W&T Homepage.

Index

| | |
|--|----|
| RS232 DTE Interface Modules, Model 188x1 | 49 |
| RS232 DCE Interface Modules, Model 188x2 | 51 |
| RS232/RS422/RS485 Interface Modules, Model 188x3 | 53 |
| RS422/RS485 Interface Modules, Model 186x1 | 61 |
| Profibus Interface Modules, Model 186x2 | 69 |
| 20mA Interface Modules, Model 184x1 | 73 |
| 20mA Interface Modules, Model 184x2 | 77 |
| POF Interface Modules, Model 181x1 | 81 |
| Fiber Optic Interface Modules, Model 1812x | 85 |
| USB Interface Module, Model 18311 | 89 |

RS232 DTE Interface Modules, #188x1**Function**

The W&T Interface Modules 18801, 18811 and 18831 provide an RS232 DTE interface for devices equipped with a serial TTL port. The modules support all RS232 data and handshaking signals. Modules 18801 and 18811/18831 differ only in the arrangement of the post connector for the serial TTL port, and are in every other respect functionally identical.

Important installation note

When installing or replacing the Interface Modules, visually inspect to ensure that the module does not cause a short circuit with adjacent components.

To use the Interface Modules with W&T PC cards, remove the wire jumper between the SUB-D male connector housing and the module. Otherwise the galvanic isolation between the interface and the PC may be defeated.

**Supply voltage**

The Interface Modules require a regulated supply voltage of 5V DC $\pm 5\%$ (18801 and 18811) and 3,3V DC $\pm 5\%$ (18831) respectively. The no-load current draw of the modules is approx. 30mA (typ.); any additional current requirement from an external load must of course be taken into account when dimensioning the power supply.

Protection against static charges

All external signal lines use ESD-immune interface components to provide protection against static discharges of up to 15kV per IEC 801-2, Level 4.

Pin configuration

The RS232 connection for the modules is configured as a 9-pin male SUB-D connector, with the TTL interface formatted as 12-pin male post connector. Refer to the following table for connector pin assignments:

TTL interface

| pin# | signal | function |
|------|----------|------------|
| 1 | 5V ±5% | Vcc |
| 2 | RI | output |
| 3 | RxD | output |
| 4 | TxD | input |
| 5 | n.c. | n.c. |
| 6 | CTS | output |
| 7 | DTR | input |
| 8 | DSR | output |
| 9 | RTS | input |
| 10 | DCD | output |
| 11 | 12V ±10% | n.c. |
| 12 | GND | signal GND |

RS232 interface

| pin# | signal | function |
|------|--------|----------|
| 1 | DCD | input |
| 2 | RxD | input |
| 3 | TxD | output |
| 4 | DTR | output |
| 5 | GND | GND |
| 6 | DSR | input |
| 7 | RTS | output |
| 8 | CTS | input |
| 9 | RI | input |

Pin 1 of the TTL interface is indicated by a rectangular soldering pad.

Technical Data

| | |
|--------------------|---|
| Baud rate: | 0..230 Kbaud |
| Data format: | any |
| Supported signals: | RxD, TxD, RTS, CTS, DSR, DCD, DTR, RI |
| ESD immunity: | up to 15kV per IEC 801-2, Level 4 using ESD-immune interface components |
| Supply voltage: | 5V DC ±5% (18801, 18811) 3,3V DC ±5% (18831) |
| Supply current: | approx. 30mA |
| TTL connector: | 12-pin, 2mm post connector |
| RS232 connector: | 9-pin male SUB-D connector |
| Dimensions: | 43 x 31 mm |
| Weight: | approx. 10g |
| Packing list: | RS232 DTE Interface Module |

RS232 DCE Interface Modules, #188x2**Function**

The W&T Interface Modules 18802 and 18812 provide an RS232 DCE interface for devices equipped with a serial TTL port. The modules support all RS232 data and handshaking signals. Modules 18802 and 18812 differ only in the arrangement of the post connector for the serial TTL port, and are in every other respect functionally identical.

Important installation note

When installing or replacing the Interface Modules, visually inspect to ensure that the module does not cause a short circuit with adjacent components.

**Supply voltage**

The Interface Modules require a regulated supply voltage of 5V DC $\pm 5\%$. The no-load current draw of the modules is approx. 30mA (typ.); any additional current requirement from an external load must of course be taken into account when dimensioning the power supply.

Protection against static charges

All external signal lines use ESD-immune interface components to provide protection against static discharges of up to 15kV per IEC 801-2, Level 4.

Pin configuration

The RS232 connection for the modules is configured as a 9-pin female SUB-D connector, with the TTL interface formatted as 12-pin male post connector. Refer to the following table for connector pin assignments:

TTL interface

| pin# | signal | function |
|------|----------|------------|
| 1 | 5V ±5% | Vcc |
| 2 | RI | input |
| 3 | TxD | output |
| 4 | RxD | input |
| 5 | n.c. | n.c. |
| 6 | DTR | output |
| 7 | CTS | input |
| 8 | DSR | input |
| 9 | RTS | output |
| 10 | DCD | input |
| 11 | 12V ±10% | n.c. |
| 12 | GND | signal GND |

RS232 interface

| pin# | signal | function |
|------|--------|----------|
| 1 | DCD | output |
| 2 | RxD | output |
| 3 | TxD | input |
| 4 | DTR | input |
| 5 | GND | GND |
| 6 | DSR | output |
| 7 | RTS | input |
| 8 | CTS | output |
| 9 | RI | output |

Pin 1 of the TTL interface is indicated by a rectangular soldering pad.

Technical Data

| | |
|--------------------|---|
| Baud rate: | 0..230 Kbaud |
| Data format: | any |
| Supported signals: | RxD, TxD, RTS, CTS, DSR, DCD, DTR, RI |
| ESD immunity: | up to 15kV per IEC 801-2, Level 4 using ESD-immune interface components |
| Supply voltage: | 5V DC ±5% |
| Supply current: | approx. 30mA |
| TTL connector: | 12-pin, 2mm post connector |
| RS232 connector: | 9-pin female SUB-D connector |
| Dimensions: | 43 x 31 mm |
| Weight: | approx. 10g |
| Packing list: | RS232 DCE Interface Module |

RS232/RS422/RS485 Interface Modules, #188x3**Function**

The W&T Interface Modules 18803, 18813 and 18833 provide an RS232, RS422 or RS485 interface for devices equipped with a serial TTL port. The Interface Module is configurable for the various operating modes via an 8-position DIL switch. Modules 18803 and 18813/18833 differ only in the arrangement of the post connector for the serial TTL port, and are in every other respect functionally identical.

Important installation note

When installing or replacing the Interface Modules, visually inspect to ensure that the module does not cause a short circuit with adjacent components. To use the Interface Modules with W&T PC cards, remove the wire jumper between the SUB-D male connector housing and the module. Otherwise the galvanic isolation between the interface and the PC may be defeated.

**Supply voltage**

The Interface Modules require a regulated supply voltage of 5V DC $\pm 5\%$ (18803 and 18813) and 3,3V DC $\pm 5\%$ (18833) respectively. The no-load current draw of the modules is approx. 40mA (typ.); any additional current requirement from an external load must of course be taken into account when dimensioning the power supply.

Protection against static charges

All external signal lines use ESD-immune interface components to provide protection against static discharges of up to 15kV per IEC 801-2, Level 4.

Pin configuration

The RS232/RS422/RS485 connection for the modules is configured as a 9-pin male SUB-D connector, with the TTL interface formatted as 12-pin male post connector. Refer to the following table for connector pin assignments:

TTL interface

| pin# | signal | RS232 | RS422/485 |
|------|---------------|------------|-------------|
| 1 | 5V \pm 5% | Vcc | Vcc |
| 2 | RI | output | "low" level |
| 3 | RxD | output | output |
| 4 | TxD | input | input |
| 5 | n.c. | n.c. | n.c. |
| 6 | CTS | output | output |
| 7 | DTR | input | input |
| 8 | DSR | output | "low" level |
| 9 | RTS | input | input |
| 10 | DCD | output | "low" level |
| 11 | 12V \pm 10% | n.c. | n.c. |
| 12 | GND | signal GND | signal GND |

Pin 1 of the TTL interface is indicated by a rectangular soldering pad.

RS232 interface

| pin# | signal | function |
|------|--------|----------|
| 1 | DCD | input |
| 2 | RxD | input |
| 3 | TxD | output |
| 4 | DTR | output |
| 5 | GND | GND |
| 6 | DSR | input |
| 7 | RTS | output |
| 8 | CTS | input |
| 9 | RI | input |

RS422/RS485 interface

| pin# | signal | function |
|------|--------|----------|
| 1 | TXD A | output |
| 2 | RxD A | input |
| 3 | DTR A | output |
| 4 | CTS A | input |
| 5 | GND | GND |
| 6 | TXD B | output |
| 7 | RxD B | input |
| 8 | DTR B | output |
| 9 | CTS B | input |

Operating modes

The Interface Modules are configurable for the following modes using DIL switches:

RS232

The Interface Module converts all available TTL data and handshake signals into RS232 signals. This mode provides one RxD and TxD channel each in the respective direction, along with six handshake channels (RTS, CTS, DSR, DCD, DTR and RI).

RS422

The Interface Module supports one data and one handshake channel each (selectable DTR or RTS handshake output). The RS422 sender/receivers are always active.

RS485

One data channel in each direction is always available in all RS485 modes. These modes differ only in how the RS485 transceivers are controlled.

RS485 4-wire bus master

In this mode the master uses a conductor pair to send requests to the slaves, which in turn send their replies to the master on an additional common conductor pair. The RS485 transceivers are always active in this mode, whereby the master can always send and is constantly listening for the slaves.

RS485 4-wire mode with handshake control

The RS485 driver chip is turned on with a TTL Low level on the „DTR“ or „RTS“ line, whereas a TTL High level on this line puts the driver in a high-impedance state. The receiving channel in this mode is always active.

RS485 2-wire mode with handshake control

The RS485 driver chip is turned on with a TTL Low level on the „DTR“ or „RTS“ line, whereas a TTL High level on this line puts the driver in a high-impedance state. The receiving channel is deactivated when the driver is on, and enabled when the driver is in the high-impedance state.

RS485 4-wire mode with automatic control

The RS485 driver chip is automatically activated whenever data are output and brought to the high-impedance state when data output is finished. The receiving channel in this mode is always active.

RS485 2-wire mode with automatic control

The RS485 driver chip is automatically activated when data are output and brought to the high-impedance state when data output is finished. The receiving channel is deactivated when the driver is turned on, and enabled when the driver is in the high-impedance state.

The DIL switch settings can be found in the following table:

| Operating mode | SW1 | SW2 | SW3 | SW4 | SW5 | SW6 | SW7 | SW8 |
|---|-----|-----|-----|-----|-----|-----|-----|-----|
| RS232 | OFF | OFF | OFF | OFF | OFF | OFF | OFF | ON |
| RS422, RS485, 4-wire bus master DTR handshake | OFF | OFF | OFF | ON | OFF | * | * | OFF |
| RS422, RS485, 4-wire bus master RTS handshake | OFF | OFF | OFF | OFF | ON | * | * | OFF |
| RS485, 4-wire / 2-wire with echo DTR control | OFF | OFF | ON | ON | OFF | * | * | OFF |
| RS485, 2-wire without echo DTR control | ON | OFF | ON | ON | OFF | * | * | OFF |
| RS485, 4-wire / 2-wire with echo RTS control | OFF | OFF | ON | OFF | ON | * | * | OFF |
| RS485, 2-Draht without echo RTS control | ON | OFF | ON | OFF | ON | * | * | OFF |
| RS485, 4-wire / 2-wire with echo automatic control | OFF | ON | OFF | ON | OFF | * | * | OFF |
| RS485, 2-wire without echo automatic control | ON | ON | OFF | ON | OFF | * | * | OFF |

**) Terminating the bus system when required.*

Important Note

The terminating DIL switches SW6 and SW7 must never be in the ON position when using the module in RS232 mode. This will result in a significant increase in the current draw and may cause the RS232 driver to fail.




Termination

All RS485 modes require termination of the bus system with a termination network. The resistor combination integrated in the module performs two tasks in RS485 applications:

1. The connected line is terminated corresponding to its impedance, which prevents signal reflections at the cable end.
2. In the high-impedance phases of bus operation a defined quiescent state is ensured.


The bus system is allowed to be terminated with the termination network only in RS485 and RS422 modes, but not in RS232 mode.

Closing DIL switches 6 and 7 on the Interface Module connects the bus terminals to the following resistance network:




Connection examples


RS232 application with hardware handshake




RS422 application with hardware handshake



RS485 4-wire bus master application



RS485 2-wire application



Technical Data

| | |
|--------------------------|--|
| Operating modes: | RS232, RS422 RS485 2- or 4-wire |
| Baud rate: | RS232: 0..230 KBAud RS422: 0..10 MBAud RS485: 0..5 MBAud |
| Data format: | any |
| Supported signals: | RS232: RxD, TxD, RTS, CTS DSR, DCD, DTR, RI RS422: RxD A/B, TxD A/B CTS A/B, DTR A/B RS485: RXD A/B, TxD A/B |
| ESD immunity: | up to 15kV per IEC 801-2, Level 4 using ESD-immune interface components |
| Supply voltage: | 5V DC $\pm 5\%$ (18803, 18813) 3,3V DC $\pm 5\%$ (18833) |
| Supply current: | approx. 40mA |
| TTL connector: | 12-pin, 2mm post connector |
| RS232/422/485 connector: | 9-pin male SUB-D connector |
| Dimensions: | 43 x 31 mm |
| Weight: | approx. 10g |
| Packing list: | RS232/RS422/RS485 Interface Module |

RS422/RS485 Interface Modules, #186x1**Function**

The W&T Interface Modules 18601, 18611 and 18631 provide an RS422 or RS485 interface for devices equipped with a serial TTL port. The Interface Module is configurable for the various operating modes via an 8-position DIL switch. Modules 18601 and 18611/18631 differ only in the arrangement of the post connector for the serial TTL port, and are in every other respect functionally identical.

Important installation note

When installing or replacing the Interface Modules, visually inspect to ensure that the module does not cause a short circuit with adjacent components.

To use the Interface Modules with W&T PC cards, remove the wire jumper between the SUB-D male connector housing and the module. Otherwise the galvanic isolation between the interface and the PC may be defeated.

**Supply voltage**

The Interface Modules require a regulated supply voltage of 5V DC $\pm 5\%$ (18601 and 18611) and 3,3V DC $\pm 5\%$ (18631) respectively. The no-load current draw of the modules is approx. 40mA (typ.); any additional current requirement from an external load must of course be taken into account when dimensioning the power supply.

Protection against static charges

All external signal lines use ESD-immune interface components to provide protection against static discharges of up to 15kV per IEC 801-2, Level 4.

Pin configuration

The RS422/RS2485 connection for the modules is configured as a 9-pin male SUB-D connector, with the TTL interface formatted as 12-pin male post connector. Refer to the following table for connector pin assignments:

TTL interface

| pin# | signal | function |
|------|---------------|--------------|
| 1 | 5V \pm 5% | Vcc |
| 2 | RI | "low" level |
| 3 | RxD | output |
| 4 | TxD | input |
| 5 | n.c. | n.c. |
| 6 | CTS | output |
| 7 | DTR | input |
| 8 | DSR | conn. to CTS |
| 9 | RTS | input |
| 10 | DCD | "low" level |
| 11 | 12V \pm 10% | n.c. |
| 12 | GND | signal GND |

RS422/RS485 interface

| pin# | signal |
|------|--------|
| 1 | TXD A |
| 2 | RxD A |
| 3 | DTR A |
| 4 | CTS A |
| 5 | GND |
| 6 | TXD B |
| 7 | RxD B |
| 8 | DTR B |
| 9 | CTS B |

Pin 1 of the TTL interface is indicated by a rectangular soldering pad.

Operating modes

The Interface Modules are configurable for the following modes using DIL switches:

RS422

The Interface Module supports one data and one handshake channel each (selectable DTR or RTS handshake output). The RS422 sender/receivers are always active.

RS485

One data channel in each direction is always available in all RS485 modes. These modes differ only in how the RS485 transceivers are controlled.

RS485 4-wire bus master

In this mode the master uses a conductor pair to send requests to the slaves, which in turn send their replies to the master on an additional common conductor pair. The RS485 transceivers are always active in this mode, whereby the master can always send and is constantly listening for the slaves.

RS485 4-wire mode with handshake control

The RS485 driver chip is turned on with a TTL Low level on the „DTR“ or „RTS“ line, whereas a TTL High level on this line puts the driver in a high-impedance state. The receiving channel in this mode is always active.

RS485 2-wire mode with handshake control

The RS485 driver chip is turned on with a TTL Low level on the „DTR“ or „RTS“ line, whereas a TTL High level on this line puts the driver in a high-impedance state. The receiving channel is deactivated when the driver is on, and enabled when the driver is in the high-impedance state.

RS485 4-wire mode with automatic control

The RS485 driver chip is automatically activated whenever data are output and brought to the high-impedance state when data output is finished. The receiving channel in this mode is always active.

RS485 2-wire mode with automatic control

The RS485 driver chip is automatically activated when data are output and brought to the high-impedance state when data output is finished. The receiving channel is deactivated when the driver is turned on, and enabled when the driver is in the high-impedance state.

The DIL switch settings can be found in the following table:

| Operating mode | SW1 | SW2 | SW3 | SW4 | SW5 | SW6 | SW7 | SW8 |
|---|-----|-----|-----|-----|-----|-----|-----|-----|
| RS422, RS485, 4-wire bus master DTR handshake | OFF | OFF | OFF | ON | OFF | * | * | OFF |
| RS422, RS485, 4-wire bus master RTS handshake | OFF | OFF | OFF | OFF | ON | * | * | OFF |
| RS485, 4-wire / 2-wire with echo DTR control | OFF | OFF | ON | ON | OFF | * | * | OFF |
| RS485, 2-wire without echo DTR control | ON | OFF | ON | ON | OFF | * | * | OFF |
| RS485, 4-wire / 2-wire with echo RTS control | OFF | OFF | ON | OFF | ON | * | * | OFF |
| RS485, 2-Draht without echo RTS control | ON | OFF | ON | OFF | ON | * | * | OFF |
| RS485, 4-wire / 2-wire with echo automatic control | OFF | ON | OFF | ON | OFF | * | * | OFF |
| RS485, 2-wire without echo automatic control | ON | ON | OFF | ON | OFF | * | * | OFF |


^{a)} Terminating the bus system when required.

Termination

All RS485 modes require termination of the bus system with a termination network. The resistor combination integrated in the module performs two tasks in RS485 applications:


1. The connected line is terminated corresponding to its impedance, which prevents signal reflections at the cable end.
2. In the high-impedance phases of bus operation a defined quiescent state is ensured.

Closing DIL switches 6 and 7 on the Interface Module connects the bus terminals to the following resistance network:




Connection examples


RS422 application with hardware handshake



RS485 4-wire bus master application



RS485 2-wire application



Technical Data

| | |
|----------------------|---|
| Operating modes: | RS422 RS485 2- or 4-wire |
| Baud rate: | RS422: 0..10 MBaud RS485: 0..5 MBaud |
| Data format: | any |
| Supported signals: | RS422: RxD A/B, TxD A/B CTS A/B, DTR A/B RS485: RXD A/B, TxD A/B |
| ESD immunity: | up to 15kV per IEC 801-2, Level 4 using ESD-immune interface components |
| Supply voltage: | 5V DC $\pm 5\%$ (18601, 18611) 3,3V DC $\pm 5\%$ (18631) |
| Supply current: | approx. 40mA |
| TTL connector: | 12-pin, 2mm post connector |
| RS422/485 connector: | 9-pin male SUB-D connector |
| Dimensions: | 43 x 31 mm |
| Weight: | approx. 10g |
| Packing list: | RS422/RS485 Interface Module |

Profibus Interface Modules, #186x2**Function**

The W&T Interface Modules 18602 and 18612 provide an RS485 2-wire-interface with Profibus pinout for devices equipped with a serial TTL port. Modules 18602 and 18612 differ only in the arrangement of the post connector for the serial TTL port, and are in every other respect functionally identical.

Important installation note

When installing or replacing the Interface Modules, visually inspect to ensure that the module does not cause a short circuit with adjacent components.

To use the Interface Modules with W&T PC cards, remove the wire jumper between the SUB-D male connector housing and the module. Otherwise the galvanic isolation between the interface and the PC may be defeated.

**Supply voltage**

The Interface Modules require a regulated supply voltage of 5V DC $\pm 5\%$. The no-load current draw of the modules is approx. 40mA (typ.); any additional current requirement from an external load must of course be taken into account when dimensioning the power supply.

Protection against static charges

All external signal lines use ESD-immune interface components to provide protection against static discharges of up to 15kV per IEC 801-2, Level 4.

Pin configuration

The Profibus connection for the modules is configured as a 9-pin female SUB-D connector, with the TTL interface formatted as 12-pin male post connector. Refer to the following table for connector pin assignments:

TTL interface

| pin# | signal | function |
|------|---------------|-------------|
| 1 | 5V \pm 5% | Vcc |
| 2 | RI | "low" level |
| 3 | RxD | output |
| 4 | TxD | input |
| 5 | n.c. | n.c. |
| 6 | CTS | "low" level |
| 7 | DTR | n.c. |
| 8 | DSR | "low" level |
| 9 | RTS | n.c. |
| 10 | DCD | "low" level |
| 11 | 12V \pm 10% | n.c. |
| 12 | GND | signal GND |

Profibus interface

| pin# | signal |
|------|-----------|
| 1 | Shield |
| 2 | n.c. |
| 3 | RxD/TxD-P |
| 4 | CNTR-P |
| 5 | DGND |
| 6 | VP |
| 7 | n.c. |
| 8 | RxD/TxD-N |
| 9 | CNTR-N |

Pin 1 of the TTL interface is indicated by a rectangular soldering pad.

Operating modes

The RS485 interface module basically operates in RS485 2-wire mode with automatic control.

One data channel in each direction is available. The RS485 output driver is activated automatically with each transmission of data, and goes to the high impedance state again after the end of transmission. The RS485 receiving channel is deactivated when the driver is on, but is switched on when the driver is in the high impedance state.

Technical Data

| | |
|---------------------|---|
| Operating mode: | RS485 2-wire mode without echo, automatic control |
| Baud rate: | 0..10 MBaud |
| Data format: | any |
| Supported signals: | RxD/TxD-P , RxD/TxD-N |
| ESD immunity: | up to 15kV per IEC 801-2, Level 4 using ESD-immune interface components |
| Supply voltage: | 5V DC \pm 5% |
| Supply current: | approx. 40mA |
| TTL connector: | 12-pin, 2mm post connector |
| Profibus connector: | 9-pin female SUB-D connector |
| Dimensions: | 43 x 31 mm |
| Weight: | approx. 10g |
| Packing list: | Profibus Interface Module |

20mA Interface Modules, #184x1**Function**

The W&T Interface Modules 18401 and 18411 provide a 20mA interface for devices equipped with a serial TTL port. The modules support one data line in each direction and can be used as an active or passive 20mA component.

In the active mode the module supplies the current required by the respective 20mA loop, while in the passive mode the loop current must be supplied by the connected device.

Modules 18401 and 18411 differ only in the arrangement of the post connector for the serial TTL port, and are in every other respect functionally identical.

Important installation note

When installing or replacing the Interface Modules, visually inspect to ensure that the module does not cause a short circuit with adjacent components.

To use the Interface Modules with W&T PC cards, remove the wire jumper between the SUB-D male connector housing and the module. Otherwise the galvanic isolation between the interface and the PC may be defeated.

**Supply voltage**

The Interface Modules require a regulated supply voltage of 5V DC $\pm 5\%$. The current draw of the modules is approx. 10mA (typ.). In active mode the modules require an additional unstabilized supply voltage of 12V DC.

Protection against static charges

All external signal lines use ESD-immune interface components to provide protection against static discharges of up to 15kV per IEC 801-2, Level 4.

Pin configuration

The 20mA connection for the modules is configured as a 9-pin male SUB-D connector, with the TTL interface formatted as 12-pin male post connector. Refer to the following table for connector pin assignments:

TTL interface

| pin# | signal | function |
|------|---------------|-------------|
| 1 | 5V \pm 5% | Vcc |
| 2 | RI | "low" level |
| 3 | RxD | output |
| 4 | TxD | input |
| 5 | n.c. | n.c. |
| 6 | CTS | "low" level |
| 7 | DTR | n.c. |
| 8 | DSR | "low" level |
| 9 | RTS | n.c. |
| 10 | DCD | "low" level |
| 11 | 12V \pm 10% | Vdd (20mA) |
| 12 | GND | signal GND |

20mA interface

| pin# | signal |
|------|---------------------|
| 1 | Data Out 20mA |
| 2 | Data Out + |
| 3 | Data Out - |
| 4 | Data Out GND |
| 5 | Half Duplex Control |
| 6 | Data In 20mA |
| 7 | Data In + |
| 8 | Data In - |
| 9 | Data In GND |

Pin 1 of the TTL interface is indicated by a rectangular soldering pad.


Operating modes

A GND level signal on Pin 5 of the SUB-D connector will place the module in half-duplex mode whereby an echo of the sent signals is suppressed. The Interface Module can be used as an active or passive 20mA component. The operating mode can be selected for both loops separately.


Connection examples

Examples of module switching into active/ passive mode are shown on the following drawings:


Active Tx and active Rx current loop application



Passive Tx and passive Rx current loop application



Active Tx and passive Rx current loop application



Technical Data

| | |
|--------------------|--|
| Operating mode: | Active and passive mode Full and halfduplex mode |
| Baud rate: | 0..19.200 Baud |
| Data format: | any |
| Supported signals: | RxD, TxD |
| ESD immunity: | up to 15kV per IEC 801-2, Level 4 using varistors |
| Supply voltage: | 5V DC \pm 5% 12V DC (in active mode only) |
| Supply current: | approx. 10mA @ 5V approx. 50mA @ 12V |
| TTL connector: | 12-pin, 2mm post connector |
| 20mA connector: | 9-pin male SUB-D connector |
| Dimensions: | 43 x 31 mm |
| Weight: | approx. 10g |
| Packing list: | 20mA Interface Module |

20mA Interface Modules, #184x2**Function**

The W&T Interface Modules 18402 and 18412 provide a 20mA interface for devices equipped with a serial TTL port. The modules support one data line in each direction and can be used as an active or passive 20mA component.

In the active mode the module supplies the current required by the respective 20mA loop, while in the passive mode the loop current must be supplied by the connected device.

Modules 18402 and 18412 differ only in the arrangement of the post connector for the serial TTL port, and are in every other respect functionally identical.

Important installation note

When installing or replacing the Interface Modules, visually inspect to ensure that the module does not cause a short circuit with adjacent components.

To use the Interface Modules with W&T PC cards, remove the wire jumper between the SUB-D male connector housing and the module. Otherwise the galvanic isolation between the interface and the PC may be defeated.

**Supply voltage**

The Interface Modules require a supply voltage between 3,3 and 5V DC. The current draw of the modules is approx. 30mA @5V (20mA @3,3V) in passive mode and 140mA @5V (210mA @3,3V) in active mode for both current loops.

Protection against static charges

All external signal lines use ESD-immune interface components to provide protection against static discharges of up to 15kV per IEC 801-2, Level 4.

Pin configuration

The 20mA connection for the modules is configured as a 9-pin male SUB-D connector, with the TTL interface formatted as 12-pin male post connector. Refer to the following table for connector pin assignments:

TTL interface

| pin# | signal | function |
|------|---------------|-------------|
| 1 | 5V \pm 5% | Vcc |
| 2 | RI | "low" level |
| 3 | RxD | output |
| 4 | TxD | input |
| 5 | n.c. | n.c. |
| 6 | CTS | "low" level |
| 7 | DTR | n.c. |
| 8 | DSR | "low" level |
| 9 | RTS | n.c. |
| 10 | DCD | "low" level |
| 11 | 12V \pm 10% | n.c. |
| 12 | GND | signal GND |

20mA interface

| pin# | signal |
|------|---------------------|
| 1 | Data Out 20mA |
| 2 | Data Out + |
| 3 | Data Out - |
| 4 | Data Out GND |
| 5 | Half Duplex Control |
| 6 | Data In 20mA |
| 7 | Data In + |
| 8 | Data In - |
| 9 | Data In GND |

Pin 1 of the TTL interface is indicated by a rectangular soldering pad.


Operating modes

A GND level signal on Pin 5 of the SUB-D connector will place the module in half-duplex mode whereby an echo of the sent signals is suppressed. The Interface Module can be used as an active or passive 20mA component. The operating mode can be selected for both loops separately.


Connection examples

Examples of module switching into active/ passive mode are shown on the following drawings:


Active Tx and active Rx current loop application



Passive Tx and passive Rx current loop application



Active Tx and passive Rx current loop application



Technical Data

| | |
|----------------------|---|
| Operating mode: | Active and passive mode Full and halfduplex mode |
| Baud rate: | 0..19.200 Baud |
| Data format: | any |
| Supported signals: | RxD, TxD |
| ESD immunity: | up to 15kV per IEC 801-2, Level 4 using varistors |
| Supply voltage: | 3,3V..5V DC |
| Min. supply current: | in passive mode: approx. 30mA @5V (20mA @3.3V) |
| Max. supply current: | both loops in active mode: approx. 140mA @5V (210mA @3,3V) |
| TTL connector: | 12-pin, 2mm post connector |
| 20mA connector: | 9-pin male SUB-D connector |
| Dimensions: | 43 x 31 mm |
| Weight: | approx. 10g |
| Packing list: | 20mA Interface Module |

POF Interface Modules, #181x1**Function**

The W&T Interface Modules 18101 and 18111 provide a plastic fiber optic interface for devices equipped with a serial TTL port. The modules support one data line in each direction and transmit data over a distance of max. 100 meters.

Modules 18101 and 18111 differ only in the arrangement of the post connector for the serial TTL port, and are in every other respect functionally identical.

The transmission medium is standard duplex plastic fiber optic cable, which is inexpensive and extremely easy to work with and install. The use of fiber optics as a transmission medium ensures perfect galvanic isolation between the connected devices and clean transmission even in noise-prone environments.


Important installation note

When installing or replacing the Interface Modules, visually inspect to ensure that the module does not cause a short circuit with adjacent components.

**Supply voltage**

The Interface Modules require a regulated supply voltage of 5V DC $\pm 5\%$. The current draw of the modules is approx. 40mA (typ.).

Module diagram



Pin configuration

The fiber optic connection for the interface is configured as a self-locking coupling for duplex plastic fiber optics, with the TTL interface formatted as 12-pin male post connector. Refer to the following table for connector pin assignments:

| TTL interface | | |
|---------------|-----------|------------------|
| Pin# | signal | funktion |
| 1 | 5V ±5% | Vcc |
| 2 | RI | n.c. |
| 3 | RxD | output |
| 4 | TxD | input |
| 5 | n.c. | n.c. |
| 6 | CTS | connected to RTS |
| 7 | DTR | connected to DSR |
| 8 | DSR | connected to DTR |
| 9 | RTS | connected to CTS |
| 10 | DCD | n.c. |
| 11 | +12V ±10% | n.c. |
| 12 | GND | signal GND |

Pin 1 of the TTL interface is indicated by a rectangular soldering pad.

Assembly

Connecting the plastic fiber optic cable to the interface requires no special tools:

- Trim the fiber optic cable to the desired length using a sharp knife. Make your cut as close to a right angle to the longitudinal axis of the cable as possible. A simple cut is generally sufficient, with no reworking required.
- Separate the individual duplex conductors back from the cut point to a distance of around 2cm.
- Pull the locking levers on the fiber optic female connector back towards the module along the upper side of the coupling.
- At the same time insert the separated end of the fiber optic duplex line into the fiber optic coupling female.
- Releasing the locking levers locks the fiber optics into the coupling.
- To release, pull the two locking levers on the top of the coupling towards the module, and pull the fiber optic cable out of the female.

The arrows on the top side of the coupling clearly show the location of the emitter and receiver lines.

Please note that when connecting two fiber optic components, the emitter of the first must always be connected to the receiver channel of the second component. A visible red light beam is always sent along with data, so that the sending line can always be easily identified.

Technical Data

| | |
|--------------------|--|
| Baud rate: | 0..115.200 Baud |
| Data format: | any |
| Supported signals: | RxD, TxD |
| Max. distance: | 100m |
| Supply voltage: | 5V DC \pm 5% |
| Supply current: | approx. 40mA |
| TTL connector: | 12-pin, 2mm post connector |
| POF connector: | Integrated socket with automatic interlocking of the fiber-optic cable |
| POF medium: | Duplex plastic optical fiber cable 2.2 x 4.4 mm, fiber diameter of 980 μ m, core: PMMA, cladding: PE |
| Dimensions: | 43 x 31 mm |
| Weight: | approx. 10g |
| Packing list: | POF Interface Module |

Fiber Optic Interface Modules, #1812x**Function**

The W&T Interface Modules 18120 and 18121 provide a fiber optic interface with ST connectors for devices equipped with a serial TTL port. Modules 18120 and 18121 differ only in the arrangement of the post connector for the serial TTL port, and are in every other respect functionally identical.

The light used for data transmission has a wavelength of 820 nm. Commonly available Multimode duplex glass fiber optic cable in 50/125 μ m or 62.5/125 μ m is used as the transmission medium, which due to its wide application in networking is easily available and cost-effective. This means that even already existing glass fiber optic lines intended for use in networks can easily be used for transmitting serial data. Depending on the attenuation of the glass fiber optic cable used, data can be transmitted over a distance of maximum 4000 meters.

Important installation note

When installing or replacing the Interface Modules, visually inspect to ensure that the module does not cause a short circuit with adjacent components.

**Supply voltage**

The Interface Modules require a regulated supply voltage of 5V DC \pm 5%. The current draw of the modules is approx. 60mA (typ.).


Pin configuration

The fiber optic connection for the modules is configured as a ST connector, with the TTL interface formatted as 12-pin male post connector. Refer to the following table for connector pin assignments:

| TTL interface | | |
|---------------|----------------|------------------|
| Pin# | signal | funktion |
| 1 | 5V \pm 5% | Vcc |
| 2 | RI | n.c. |
| 3 | RxD | output |
| 4 | TxD | input |
| 5 | n.c. | n.c. |
| 6 | CTS | connected to RTS |
| 7 | DTR | connected to DSR |
| 8 | DSR | connected to DTR |
| 9 | RTS | connected to CTS |
| 10 | DCD | n.c. |
| 11 | +12V \pm 10% | n.c. |
| 12 | GND | signal GND |

Pin 1 of the TTL interface is indicated by a rectangular soldering pad.

Module diagram



Technical Data

| | |
|---------------------|--|
| Baud rate: | 0..1,5 Mbaud |
| Data format: | any |
| Supported signals: | RxD, TxD |
| Fiber-optic medium: | Duplex multimode fiber-optic cable |
| Max. distance: | 50/125 μ m: typ. 3500m, min. 2200m @3dB/km 62.5/125 μ m: typ. 4000m, min. 3000m @3.5dB/km 200 μ m PCS fiber: typ. 2700m, min. 2500m @8dB/km |
| Optical budget: | 50/125 μ m: typically 10.5dB, min. 6.6dB 62.5/125 μ m: typically 15dB, min. 10.5dB 200 μ m PCS fiber: typically 21.5dB, min. 20dB |
| Supply voltage: | 5V DC \pm 5% |
| Supply current: | approx. 60mA |
| TTL connector: | 12-pin, 2mm post connector |
| FO cable connector: | ST plug adapter SMA plug adapter on request |
| Dimensions: | 55 x 31 mm |
| Weight: | approx. 10g |
| Packing list: | Fiber Optic Interface Module |

Interface Module USB, #18311**Function**

The W&T Interface Module 18311 equips devices having a serial TTL interface with a USB slave interface.

The module uses an integrated serial EEPROM for non-volatile storage of Vendor ID, Product ID, Serial Number and a product description. The EEPROM is programmable on-board via USB.

Current drivers for all supported Windows versions are available via the Internet on the module data sheet page.

Supply voltage

The USB interface module requires a regulated DC voltage of 5V DC $\pm 5\%$ at typ. 30 mA.

Important installation notes

When installing or replacing the Interface Modules you must visual inspect to be sure that the module is not causing any short circuit to adjacent components.




Wiring configuration

The USB connection on the module is implemented as a USB female of type „B“, and the TTL interface on the module as a 12-pole header connector. The connector pin configuration is shown in the following table.

| pin# | signal | function |
|------|---------------|------------|
| 1 | 5V \pm 5% | Vcc |
| 2 | RI | input |
| 3 | TxD | output |
| 4 | RxD | input |
| 5 | n.c. | n.c. |
| 6 | DTR | output |
| 7 | CTS | input |
| 8 | DSR | input |
| 9 | RTS | output |
| 10 | DCD | input |
| 11 | 12V \pm 10% | n.c. |
| 12 | GND | signal GND |

Pin 1 of the TTL interface is indicated by a square solder eye.

Module drawing:



Technical Data

| | |
|--------------------|--|
| Baud rate: | 300 baud..3 MBaud adjustable baud rates = 3 MBaud/n, with n = 1..16383 |
| Data bits: | 7 or 8 |
| Stop bits: | 1 or 2 |
| Parity: | no, even, odd, mark space |
| Supported signals: | RxD, TxD, RTS, CTS, DSR, DCD, DTR, RI |
| Integrated memory: | 384-byte receive buffer 128- byte send buffer |
| Supply voltage: | 5V DC \pm 5% |
| Quiescent current: | approx. 25 mA |
| TTL connection: | 12-pole 2mm header |
| USB connection: | USB female, Type B |
| Dimensions: | 55 x 31 mm |
| Weight: | approx. 10g |
| Scope of delivery: | USB Interface Module |

