

# **Manual**

## **Web-IO Analog-In + AC Current Transducer 0..50A**



Type  
Model  
Release

10/100BaseT, 12-24V  
57644  
1.2, Aug 2006

© 08/2006 by Wiesemann & Theis GmbH

Microsoft, MS-DOS, Windows, Winsock and Visual Basic are registered trademarks of the Microsoft Corporation

Subject to errors and modifications:


Since we can make mistakes, none of our statements should be taken without verification. Please inform us of any mistakes or misunderstandings you notice so that we can become aware of them and remedy them as quickly as possible.

Perform work on and with W&T products only as described and after you have read and understood this manual thoroughly. Improper use may result in hazards. We are not liable for improper use. In case of doubt please check with us or your dealer first!

## Introduction

The W&T Web-IO Analog-In incl. the AC current transducer 0..50A incorporate all the functions in one box for capturing, storing and displaying your current measurement values. A variety of alarm functions is also available which can be custom implemented in your own applications or in existing systems.

This manual contains all the information you need for installing, configuring and operating the devices.



**Table of Contents**

<b>Introduction .....</b>	<b>3</b>
<b>1 Quick Start-up .....</b>	<b>6</b>
1.1 Connecting the supply voltage .....	6
1.2 Construction of the AC current transducer 0..50A .....	6
1.3 Connecting the measurement lines .....	7
1.4 Assigning the IP address using „WuTility“ .....	9
1.5 Assigning the basic network parameters .....	11
<b>2 Additional basic settings .....</b>	<b>14</b>
2.1 Configuring the port and device names .....	14
2.2 Local time setting .....	16
2.3 Automatic time setting using a network time service .....	19
2.4 Configuring the data logger .....	20
2.5 Configuring the graphics display .....	22
2.6 Calibration .....	24
2.7 Browser access .....	26
2.8 E-mail alarms .....	27
2.9 SNMP incl. alarm sending via Trap .....	34
2.10 Sending alarms via TCP (Client Mode) .....	37
2.11 Sending alarms via FTP (Client Mode) .....	39
2.12 Sending alarms via Syslog .....	42
2.13 ASCII command strings via TCP Port 80 .....	43
2.14 ASCII command strings via UDP .....	44
2.15 UP-/Download .....	45
<b>3 Individual querying of measured values .....</b>	<b>47</b>
3.1 Querying via TCP/IP .....	47
3.2 Querying via UDP .....	47
3.3 Querying via SNMP .....	48
<b>4 Java Applets - Auto-updating in the browser .....</b>	<b>50</b>
4.1 Working with the Java applet .....	50
4.2 Using the applet with JavaScript .....	52

**5 Data Logger ..... 55**

**6 Appendix ..... 56**

6.1 Alternate IP address assignment ..... 56

6.2 Example for creating your own Web pages ..... 59

6.3 Firmware update ..... 67

    6.3.1 Where do I obtain the current firmware? ..... 67

    6.3.2 Firmware update over the network under Windows ... 67

    6.3.3 LED indicators ..... 69

6.4 Technical Data ..... 71


6.5 Declaration of Conformity ..... 72

## 1 Quick Start-up

It takes only a few steps to start up the Web-IO Analog-IN module and make it visible in your network.


### 1.1 Connecting the supply voltage

Bottom 5764X



Connect 12-24V AC/DC to the terminal provided using the plug-in power supply included. Polarity is uncritical.

### 1.2 Construcion of the AC current transducer 0..50A



Lead the wire which should be measured through the portable measuring head.



*Please make sure that only one single cable core is leaded through the device.*

Connect the supply voltage and the measurement output with the marked pins on the screw terminal.

### **1.3 Connecting the measurement lines**



Screw the measuring lines into the 6-pole female connector provided and plug it into the device.

## 1.3.1 Terminal designations

U1+ : Voltage input 1 0..10V



U2+ : Voltage input 2 0..10V

GND : Ground



*Please note when wiring the inputs that they use the same GND internally.*

## 1.3.2 Connecting the AC current transducer to the Web-IO Analog-In



## 1.4 Assigning the IP address using „WuTility“

Once the hardware has been connected to the supply voltage as described above, you must assign the IP address needed for operation in a TCP/IP network. You can obtain the correct value for this parameter from your system administrator.



*The IP address must be unique throughout the network.*

There are various ways of assigning the IP address. To make it as convenient as possible, we have developed the „WuTility“ tool, which you can download from the WuT homepage at <http://www.wut.de>. This procedure is described in the following. A summary of the alternatives can be found in the Appendix to this manual under 6.1.

Be sure that the PC you are using to assign the IP address is located in the same sub-network as the module and that both the PC and the module are connected to the network.

When it starts, *WuTility* automatically searches the local network for connected W&T network devices and generates an inventory list. This search process can be repeated manually as often as desired by clicking the *Scan* button:



Select from the displayed list your Web-IO Analog-In based on the MAC address:



Click on the „IP address“ symbol:



In the resulting window enter the desired network parameters for the device and confirm by clicking on „Continue“.

The dialog box is titled "New Device: Set Network Parameters" and contains the following fields and controls:

- IP address (must be unique):** A series of four spin boxes containing the values 172, 16, 232, and 29.
- Address range:** A dropdown menu currently set to "Subnet #0".
- Warning:** A yellow warning triangle icon followed by the text: "On a TCP/IP network, there must never be two devices with the same IP address. Please make sure that the above IP address has not been assigned to someone else, and that it is not part of a DHCP address pool, either. When in doubt about available addresses, ask your network administrator."
- Subnet mask:** A series of four spin boxes containing the values 255, 255, 255, and 0.
- Default gateway:** A series of four spin boxes containing the values 172, 16, 232, and 252.
- Buttons:** "< Back", "Next >", and "Cancel".

The BOOTP client of the Web-IO Analog-In can be activated in the following window.

The dialog box is titled "New Device: Advanced Features" and contains the following options and text:

- Enable BOOTP**  
BOOTP provides a means for centralized assignment of IP addresses. Obviously you do not need it for this device (because you chose this method of assigning an IP address instead).  
Moreover, the BOOTP option can cause problems in combination with some DHCP servers (devices getting random new IP addresses over and over again). We therefore recommend that you disable BOOTP at this point.
- Enable Web-based management**  
on TCP port: 80  
The Web-based management (WBM) option lets you configure your serial Com-Servers using a standard Web browser.  
WBM is most useful on TCP port 80. That is the standard port for HTTP, to which all Web browsers will connect by default.
- Buttons:** "< Back", "Next >", and "Cancel".


Clicking on the *Continue* button assigns the network parameters to the Web-IO Analog-In. All the columns in the device list in WuTility are filled with information. After clicking on the globe in the WuTility menu list your standard browser is opened and you will see the start page for the device.

## 1.5 Assigning the basic network parameters

In the configuration tree at left click on „Config“.



You are now prompted to enter a password. The factory default setting is for no password, so that you can simply click on the Login button without entering a password.



[zurück zur Web-IO Thermometer Homepage](#)

On the next page select the configuration path with the aid of the profiles.

Login Rights:  
Config  
Admin

Navigate with the tree on the left side. Avoid the use of the buttons "Next" and "Back" of your browser, this might cancel your changes of configuration data.

The "profiles" provides an easy way to make the required modification step by step.



Select the profile „Basic network parameters“ and click on the „Show profile“ button.

- No profile (expert mode)

**Basic configuration:**

- Basic network parameter
- Configuration of port and device name
- Local clock settings
- Automatic clock settings with the network time service
- Configuration of the data logger
- Configuration of the graphics settings
- Calibration

**Direct user control:**

- HTTP access

**Integration in existing systems:**


- Alarm via E-Mail
- SNMP incl. alarm via trap
- Alarm via TCP (client mode)
- Syslog messages incl. alarm
- Alarm via FTP (client mode)

**Access from individual programm:**

- ASCII command strings via TCP port 80
- ASCII command strings via UDP



The device now automatically displays the necessary menu points for this profile. Click on „**Network**“ in the configuration menu.



On the following page enter all the necessary network parameters and when you are finished click on the „Logout“ button.

**Config >> Device >> Basic Settings >> Network**

**IP Addr :**

**Subnet Mask :**

**Gateway :**

**BOOTP Client :** BOOTP or DHCP can only be used if the respective entry on the DHCP server assigns a reserved IP address. Important: If you are in doubt, check 'BOOTP disable'.  
 BOOTP disable

**DnsServer1 :** IP address of DNS server (format xxx.xxx.xxx.xxx)

**DnsServer2 :** IP address of DNS server (format xxx.xxx.xxx.xxx)

Free memory: 49440 bytes

Then clicking on the „Save“ button saves the settings in the device and closes your configuration session. After the network parameters have been changed the device automatically restarts itself.

**Config >> Session Control >> LogOut**

Save new configuration

Exit without saving


Restore Factory Defaults

The device is now ready for use in your network. For convenience you can use the additional profiles for adapting the unit to your specific needs.

## 2 Additional basic settings

### 2.1 Configuring the port and device names

Highlight Profile



#### 2.1.1 Text



Enter your personal descriptions in the field provided and then click on „Send“.

Config >> Device >> Text

**Device Name:** Name of device

**Device Text:** Description  
  
(For a new line use <br>)


**Location:** Location of installation

**Contact:** Contact address

Free memory: 48329 bytes

# W&T

## 2.1.2 Ports



### Port 1..2:

First enter a name and a descriptive text for the port and select the measuring range to calibrate the input circuit to your measuring location (for models 57641, 57642 only: measuring range 0..20mA or 4..20mA). To deactivate the port, select „Disconnect“.

### Configuring the voltage input:


**Config >> Ports >> Port 2**

**Name :**

**Text :**   
( For a new line use <br> )

**Select Sensor :**  0 - 10V  
 Disconnect

## 2.2 Local time setting



### 2.2.1 Time zone



Here you define the time zone in which the device is located. The settings refer to UTC (Coordinated Universal Time). Then click on „Send“.

**Config >> Device >> Time/Date >> TimeZone**

**UTCoffset :** Offset to UTC  
 :

**Enable :**  Apply Time Zone

Free memory: 49421 bytes

## 2.2.2 Summer time



If you want your unit to automatically switch to daylight savings time, first enter the offset to UTC. The standard value (for Germany etc.) is two hours. Activate this function by selecting „Apply Summertime“ and buffer store the settings („Send“).

**Config >> Device >> Time/Date >> TimeZone >> Summertime**

**UTCoffset :** Offset to UTC  
[ 02 ] : [ 00 ]

**Enable :**  Apply Summertime

Free memory: 49421 bytes



### Start/Stop



Define when daylight savings time begins and ends. The parameters are already pre-configured:

Start:

**Last Sunday in March at 02:00 hours**

Stop:

**Last Sunday in October at 03:00 hours**

Config >> Device >> Time/Date >> TimeZone >> Summertime >> Start

**Month :** Summer time starts in

**Mode :** on

**Weekday :**

**Time :**  :

Free memory: 49421 bytes

### 2.2.3 Device Clock



If you choose not to use a timeserver, this allows you to set the clock manually. Then click on „Logout“ and save your settings.

Config >> Device >> Time/Date >> Device Clock

**Time :**  :


**Day :**

**Month :**

**Year :**

Free memory: 49421 bytes

## 2.3 Automatic time setting using a network time service



### 2.3.1 Time Server



If you want to adjust the time using a time server, enter here the necessary information. The preset addresses are just an example and do not necessarily have to be used.

Config >> Device >> Time/Date >> Time Server

**UTC Server1 :** Name or IP address of the time server (format xxx.xxx.xxx.xxx).

de.pool.ntp.org

**UTC Server2 :** Name or IP address of the time server (format xxx.xxx.xxx.xxx).

europe.pool.ntp.org

**Sync.Time :** Daily synchronisation time with the time server (hour: 0-23).

0

**Enable :**  Apply TimeServer

Free memory: 49421 bytes



## W&T




If you enter a name as the address, be sure that you first have configured the Gateway and DNS server so that the device can resolve the addresses.

Click on the „Logout“ button and save your settings.

## 2.4 Configuring the data logger

Highlight Profile



### 2.4.1 Select



Make the following settings:

**Timebase:** Defines at what time interval the measured data are stored in the data logger. The device measures in any case every four seconds.

**Select Sensor:** The sensor selected here is used for saving the values in the data logger.

**Config >> Device >> Data Logger >> Select**

**Timebase :**

**Select Sensor :**  Sensor 1

**Graphics selection :**  Sensor 1

**Color Sensor 1 :**  

**Memory size :** 22 days, 18 hrs., 0 min.

Free memory: 49421 bytes



## 2.4.2 Clear



Clicking on the „Clear memory“ button deletes the entire contents of the data logger.


**Config >> Device >> Data Logger >> Clear**

Erase all flash data.



## 2.5 Configuring the graphics display

Highlight Profile



### 2.5.1 Select



Config >> Device >> Data Logger >> Select

Timebase : 1 min

Select Sensor :  Sensor 1

Graphics selection :  Sensor 1

Color Sensor 1 : 0000FF

Memory size : 22 days, 18 hrs., 0 min.

Free memory: 49421 bytes

Temporary Storage Undo Logout

## W&T

**Graphics Selection:** The selected sensor is represented in the graphics display.

**Color Sensor X:**



Defines the curve color of the sensor in the graphics display.

### 2.5.2 Graphics



Here you set the desired scaling for the displayed temperature curves:

**Config >> Device >> Data Logger >> Graphics**

**Horizontal zoom :**


Free memory: 45861 bytes



**Horizontal Zoom:** Specifies the scaling for the time axis.

## 2.6 Calibration

Highlight Profile



You can calibrate the port with the help of single-point, two-point reference measurements and corresponding offset value entries.

In single-point compensation the entered value is added to the measured value, whereas in two-point compensation a straight line is calculated for compensating the entire measuring range.

The user can enter a comment for remembering calibration procedures.

Offset 1 :

<b>Calibration</b> <b>Optionally, 1-point or 2-point calibration can be chosen.</b>	
1 point compensation	Only Offset 1 is needed: this offset is added to every measured value.
2 point compensation	Offset 1 is the offset at temperature 1, Offset 2 is the offset at temperature 2. From these 2 offsets, a straight line will be interpolated, from which the offset for each measured value is calculated. The difference between the two temperatures entered here must be greater than 40° Celsius.
All values in [ mA ] in the form xx.xxx .	

Value 1 :

Offset 2 :

Value 2 :

Comment : Comments: date, name of operator, reference devices

Free memory: 48329 bytes

## Config:

If you want the measured value to correspond to a certain physical quantity (e.g. 10mA corresponds to 50hPa), you can configure the display value for 0% to 100% of the measuring range including the associated unit. This configuration is used for all outputs.

**Config >> Ports >> Port 1 >> Config**

**Unit :** Displayed Unit


**Scale 0% :** Displayed value at 0%

**Scale 100% :** Displayed value at 100%

Free memory: 48329 bytes

## 2.7 Browser access

Highlight Profile



### 2.7.1 HTTP



**Startup:** Here you specify which HTML page should be displayed when the device starts up.

Config >> Device >> Basic Settings >> HTTP

**Startup :**

index.htm	Show navigation tree as well as page 'home'.
home.htm	Show page 'home' without navigation tree.
user.htm	Show page 'user' without navigation tree.

index.htm  
 home.htm  
 user.htm

**Enable :** Device will send header with IP address and its name before each reply to any GET requests which do not come from a browser.  
 GET Header enable

**HTTP Port :** Default: Port 80

Free memory: 49421 bytes

Temporary Storage    Undo    Logout


# W&T

**HTTP Port:** You can use this port to access the device. The default setting is the standard HTTP Port 80. If you would like to use a different port, it may have to be explicitly indicated when the page is opened:

`http://webio:<PortNr>`

## 2.8 E-mail alarms

Highlight Profile



### 2.8.1 Basic Settings -> Mail



Here you make the basic settings for sending alarms via e-mail.

## Config >> Device >> Basic Settings >> Mail

**Name :**

**ReplyAddr :**

**MailServer :** Name or IP address of the mail server (format xxx.xxx.xxx.xxx).  
 

---

**Authentication :**

- SMTP authentication off
- ESMTP
- SMTP after POP3

**User :**

**Password :**

**Retype Password :**

**POP3 Server :** Name or IP address of the POP3 mailserv (format xxx.xxx.xxx.xxx) only for 'SMTP after POP3'  
 

---

**Enable :**  Mail enable

Free memory: 48329 bytes

The e-mail function allows you to forward an information or alarm mail to one or more e-mail or SMS recipients.

**Name:** Enter here the name that should appear as the sender.

**ReplyAddr:** This is the reply address with which the device identifies itself.

**MailServer:** In the next step set the IP address of your mail server or its host name (for a configured DNS server) you want the device to use. If the e-mail port does is not the standard port 25, you may append the port to the address using a colon:

## W&T

mail.provider.de:476

**Authentication:** If the mail server requires authentication, set here the corresponding procedure for user identification.

***SMTP authentication off:*** No authentication

***ESMTP:*** A user name and password are required for logging in to the mail server.

***SMTP after POP3:*** For an SMTP access it is necessary to first make access using POP3 so that the user can be identified. For this setting enter in addition an associated POP3 server.

**Enable:** Be sure that the checkbox „Mail enable“ for sending e-mail is checked.

## 2.8.2 Alarm X



Here you configure the desired alarm conditions.

**Config >> Device >> Alarm >> Alarm 1**

- Trigger :**
- Sensor 1
  - Sensor 2
  - Timer
  - Cold Start
  - Warm Start
- 

### **Sensor 1 0-10V**

**Min :** Limit in [ V ] (Form: xx.xxx).

**Max :** Limit in [ V ] (Form: xx.xxx).

**Hysteresis :** Hysteresis in [ V ] (Form: xx.xxx).

---

### **Sensor 2 0-10V**

**Min :** Limit in [ V ] (Form: xx.xxx).

**Max :** Limit in [ V ] (Form: xx.xxx).

**Hysteresis :** Hysteresis in [ V ] (Form: xx.xxx).

# W&T

**Delay Time :** The alarm will be send after the alarm condition stay stable during this periode of time (time in minutes).

**Interval :** Sending interval in minutes

**Timer :** Alarm output triggered by internal clock.

Field	Input [ Number * , - / ]	Range of values
<b>Minute</b>	<input type="text" value="0,15,30,45"/>	0-59
<b>Hour</b>	<input type="text" value="8-17"/>	0-23 (0 is midnight)
<b>Day_of_month</b>	<input type="text" value="*"/>	1-31
<b>Month</b>	<input type="text" value="*"/>	1-12
<b>Weekday</b>	<input type="text" value="*"/>	0-6 (0 is sunday)

- Enable :**
- Mail enable
  - SNMP Trap enable
  - TCP Client enable
  - Syslog Messages enable
  - FTP Client enable

Free memory: 48329 bytes

**Trigger:** Here you define the trigger for the alarm e-mail. Multiple selections are allowed.

To send a message without an alarm condition, check only the „Timer“ box.

**Min./Max.:** Specifies the lower and upper limit. The range within these limits is considered „valid“.

**Hysteresis:** You can also specify a hysteresis value based on which the alarm status is reset. This function prevents ‚flickering‘ around the limit value.

## W&T

**Delay Time:** Triggering of the alarm is delayed by this time (in minutes) for momentary limit violations.

**Interval:** Enter here the send interval (in minutes) at which a message should be sent assuming the alarm function is enabled. If you want to send just a single message, enter here an „E“.

**Timer:** This timer interval is based on the CRON service such as is used in Linux/Unix systems. Valid characters are:

\* : stands for all valid values in the respective input field (e.g. all minutes or all hours)

- : specifies a range of from ... to .. For example, weekday „2-4“ stands for Tuesday to Thursday, whereas entering a „\*“ triggers the timer on all weekdays.

/ : Interval within the entered range , e.g. minute „0-45/2“ starts the timer in the range between the 0th and 45th minute every two minutes (0, 2, 4, 6 ,8, 10, ... , 44).

, : specifies an absolute value. For example minute 0, 15, 30 starts the timer on the hour, quarter-hour and half=hour.

This function requires that the „Timer“ box be checked.

**Enable:** For selecting the type of message. For an e-mail alarm check the Mail enable“ box.

## 2.8.3 Alarm X -> Mail



The actual content of the e-mail is selected under this menu item.

Config >> Device >> Alarm >> Alarm 1 >> Mail

**E-Mail-Addr :**

**Subject :**

**Mai~~l~~text :**

**Options :**  
 Attach Thermo.csv enable  
 CSV-Data since last report

**Alarm Clear Subject :** This messages will be send if alarm state is cleared.

**Alarm Clear Text :**

Free memory: 45584 bytes

**E-Mail-Addr:** Enter here the e-mail address of the recipient. To send the e-mail to multiple recipients, separate the addresses from each other with a semicolon.

**Subject:** Specifies the Subject line of the e-mail.

**Mailtext:** Here you enter the actual e-mail text. This text box accepts the following tags in addition:

**<M1>** Shows the current measured value for the 1st port at this position.

**<M2>** Shows the current measured value for the 2nd port at this position. You can use M1 and M2 in the subject field either.

**<Z>** Shows the current time and date.

## W&T

**Attach thermo.csv enable:** The „Attach therno.csv enable“ option allows you to attach the entire contents of the data logger in semicolon-delineated CSV format as a mail attachment. The time base for the output corresponds to the pre-settings you have made for the data logger.



*The file is generated dynamically in the unit, so that when the contents of the logger is large the assembly of the CSV-file may take up to 30 seconds. During this time no other mail may be sent. Pending alarms are executed directly after the mail with attachment has been sent.*

**CSV-Data since last report:** This option causes that only the data is written into the CSV file, which is measured since the last transmission interval.




*This function only works properly if only the timer function is selected and no limit values are configured.*

**Alarm Clear Text:** In addition, an Alarm Clear message is sent when the measured value has reentered the valid zone. Here you may use the same tags as for the alarm message itself.

## 2.9 SNMP incl. alarm sending via Trap

Highlight Profile



## W&T

Sending alarm messages as an SNMP trap.

### 2.9.1 Basic Settings -> SNMP



Here you define the basic settings needed for SNMP operation.

**Community String: Read:** Use this string to read the configuration in your SNMP manager.

**Community String: Read-Write:** Use this string to both read and write the configuration in your SNMP manager.

**Manager IP:** Contains the address of your SNMP manager. The SNMP messages from the W&T unit are sent to this address.

**System Traps:** Two system traps can be created.

Cold Start: When power is disconnected/fails.

Warm Start: At device reset.

**SNMP Enable:** To use the SHMP functionality, check this box.

## Config >> Device >> Basic Settings >> SNMP

**Community string: Read :**

**Community string: Read-Write :**

**Manager IP :** SNMP System Traps:  
Name or IP address of the SNMP manager (format xxx.xxx.xxx.xxx)

**System Traps :**  Cold Start  
 Warm Start

**Enable :**  SNMP enable

Free memory: 49421 bytes

## 2.9.2 Alarm X -> SNMP



The actual contents of the SNMP trap is specified under this menu item.

## Config >> Device >> Alarm >> Alarm 1 >> SNMP

**Manager IP :** Name or IP address of the SNMP manager (format xxx.xxx.xxx.xxx)

**Trap Text :**

**Alarm Clear Text :** This messages will be send if alarm state is cleared.

Free memory: 45861 bytes

## W&T

**Manager IP:** Contains the IP address of your SNMP manager. The SNMP messages from the W&T unit are sent to this address.

**Trap Text:** Here you enter the actual trap text. The following tags are also accepted in this text box:


<M1> Shows the current measured value for the 1st port at this position.

<M2> Shows the current measured value for the 2nd port at this position.

<Z> Shows the current time and date.

**Alarm Clear Text:** In addition, an Alarm Clear message is sent when the temperature value has reentered the valid zone. Here you may use the same tags as for the alarm message itself.

### 2.10 Sending alarms via TCP (Client Mode)



Send alarm messages as a TCP packet.

## 2.10.1 Alarm X -> TCP:



**IP Addr:** The IP address where you want the message sent.

**Port:** The recipient must have a TCP server service on this port which can accept incoming connections.

**TCP Text:** The text corresponds to the same specifications as for the other message types.

**Alarm Clear Text:** s.o.

Config >> Device >> Alarm >> Alarm 1 >> TCP

**IP Addr:** Name or IP address of the TCP server (format xxx.xxx.xxx.xxx)

192.168.0.3

**Port:**

8000

**TCP Text:**

current too high! <M1> A

**Alarm Clear Text:**

This messages will be send if alarm state is cleared.

current ok! <M1> A


Free memory: 45773 bytes

Temporary Storage

Undo

Logout

## 2.11 Sending alarms via FTP (Client Mode)



Write the measured values to an FTP server.

### 2.11.1 Basic Settings -> FTP



Here you will find the basic settings needed for FTP operation.

**FTP Server IP:** Enter here the IP address or the host name of the FTP server you want to send the data to.

**FTP Control Port:** This is the port needed for the connection. The standard port for FTP access is 21. This port is already set as shipped, and should function on most systems right out of the box. If you require a different port, consult your network administrator.

**User:** Enter the user name required for the FTP access.

**Password:** This is the password assigned to the user.

## W&T

**FTP Account:** Some FTP servers require a special Account entry for the login. If this is the case for your server, enter the account name here.

**Options / PASV:** If this option is enabled the server is instructed to work in passive mode. This means that the data connection is opened by the Web-Thermo-Hygrograph. If this option is disabled the FTP server handles opening of the data connection. If the server is protected by a firewall, you are encouraged to enable the PASV option, since otherwise connection attempts could be blocked.

**Enable:** Check this box to use the FTP functionality.

### Config >> Device >> Basic Settings >> FTP

**FTP Server IP :** Name or IP address of the FTP server (format xxx.xxx.xxx.xxx)

192.168.0.5 

**FTP Control Port :** Port No.: 1...65536 (default 21)

21

**User :**

user

**Password :**

password

**FTP Account :**

account

**Options :**

Switch FTP server into Passiv Mode.  
(possibly necessary in a firewall environment)

PASV

**Enable :**

FTP enable

Free memory: 49003 bytes

Temporary Storage 

Undo

Logout

## W&T

### 2.11.2 Alarm X -> FTP

**FTP Local Data Port:** This is the local data port on the Web-Thermo-Hygrograph. Values between 1 and 65536 are permitted. Entering „AUTO“ causes the device to select the port dynamically.

**File Name:** Enter here the path to the file you want the device to access.

**FTP Alarm Text:** Here you define the content of the file. The following tags may be used:

<M1> Shows the current measured value for the 1st port at this position.

<M2> Shows the current measured value for the 2nd port at this position.

<Z> Shows the current time and date.

If you want a line feed after every data send, insert a CRLF by pressing the RETURN key at the end of the line.

**Alarm Clear Text:** This message is sent after the alarm state is ended. The same tags as above may be used.

#### Options:

**STORE:** Stores a file and writes the data into it. If this file already exists, it is overwritten.

**APPEND:** Appends the data to an existing file. If the file does not yet exist, it is created.

## Config >> Device >> Alarm >> Alarm 1 >> FTP

**FTP Local Data Port :** Port No.: 1...65536 or AUTO = assign next free port number.

AUTO

**File Name :** /directory/values.txt

**FTP Alarm Text :** <M1> mA , <M2> V

**Alarm Clear Text :** This messages will be send if alarm state is cleared.

**Options :**  STORE  
 APPEND

Free memory: 48329 bytes

Temporary Storage

Undo

Logout

## 2.12 Sending alarms via Syslog



**IP Addr:** This is the IP address you want the message sent to.


**Port:** On the receiver end there must be a Syslog server service on this port which can accept incoming connections (Standard: 514).

**Syslog Text:** The text is subject to the same specifications as apply to the other message types.

**Alarm Clear Text:** see above

## 2.13 ASCII command strings via TCP Port 80

Highlight Profile



### 2.13.1 HTTP



When queried by an HTTP Get command, the device can also send a header with IP address and name of the device along with the measured value. To enable this, check the corresponding box. If this function is deactivated, only the measured value is sent.

#### Config >> Device >> Basic Settings >> HTTP

Startup :

index.htm	Show navigation tree as well as page 'home'.
home.htm	Show page 'home' without navigation tree.
user.htm	Show page 'user' without navigation tree.

- index.htm
- home.htm
- user.htm

**Enable :** Device will send header with IP address and its name before each reply to any GET requests which do not come from a browser.

GET Header enable


**HTTP Port :** Default, Port 80

80

Free memory: 49421 bytes

Temporary Storage    Undo    Logout

## 2.14 ASCII command strings via UDP



In addition to TCP/IP commands the device can also reply to UDP datagrams. For this the port which the device is supposed to „listen“ to must be set. The default setting is 42279. The enable function turns UDP on.

**Config >> Device >> Basic Settings >> UDP**

**Port :** Port No.: 1...65535

**Enable :**  UDP enable

Free memory: 49421 bytes



Here again you may include the header, which is included with the measured value.

## 2.15 UP-/Download



In the Download area you can download the XML configuration as well as the three user pages (home.htm, user.htm, log.htm) for further processing.

With **XML** download you can read out the Web-IO Analog-In settings, make any changes and save them to the device using **XML Upload**.



*Some Web browsers the correct code is only output using „View -> Show (Frame-) source text“ after the „XML Download“ button has been actuated.*

For XML Upload you create or change a text file using the corresponding parameters and load this file into the device. The Web-IO Analog-In configuration must begin with the expression

```
<io-AIN2.3>
```

and end with the expression

```
</io-AIN2.3>
```

The sequence of the parameters you set corresponds to the sequence in the configuration menu starting with „Device“.

The syntax for configuring using XML is as follows:

```
<Option>  
  <Parameter1> WERT </Parameter1>  
  <Parameter2> WERT </Parameter2>  
</Option>
```

Des weiteren lassen sich im **Upload** Bereich die User-Seiten (user.htm, home.htm, log.htm) austauschen.

An example can be found in the Appendix (6.2).

## W&T

The individual options and parameters correspond to the configuration items in the browser menu.



*Please note, especially when carrying out mass updates or configurations, the IP address stored in the XML file is always sent also, and that it must first be set accordingly.*

*The user pages (user.htm, home.htm, log.htm) may also be exchanged in the **Upload** area.*

*An example can be found in the Appendix (6.2).*

You may use menu item „**Upload -> GIF**“ to exchange the logo displayed in the menu and save it directly in the W&T device.

## 3 Individual querying of measured values

### 3.1 Querying via TCP/IP

It is possible to use a socket connection for manually querying the current measurements in CSV format (comma separated data). This function as well is used for querying the single data without the Web interface.

Send the following string to Port 80:

```
GET /logger.csv
```

To query the single, current measured value on Port 1, send:

```
GET /Single1
```

To query the single, current measured value on Port 2, send:

```
GET /Single2
```

### 3.2 Querying via UDP

Open a UDP connection to the IP address of the device or to the NED ID as a broadcast and Port 42279 (preset is modifiable).

Then send one of the expressions listed under 3.1 to the device and the device will return the measured values on the port you are using.



*When using multiple devices, it may be practical to send the name and the IP address of the device at the same time. To do this, activate the item „GET Header enable“ under „Config >> Device >> Basic Settings >> HTTP“.*

## 3.3 Querying via SNMP

The sensor can be queried directly using SNMP Get instructions. You reach the measuring port through the following path:

<IP-Address> 1.3.6.1.4.1.5040.1.2.10.1.3.1.1.1 = Measured value 1 as octet string.

<IP-Address> 1.3.6.1.4.1.5040.1.2.10.1.4.1.1.1 = Measured value as integer value in thousandths, without comma separation.

<IP-Address> 1.3.6.1.4.1.5040.1.2.10.1.3.1.1.2 = Measured value 1 as octet string.

<IP-Adresse> 1.3.6.1.4.1.5040.1.2.10.1.4.1.1.2 = Measured value 2 als Integer-Wert in tausendstel, ohne Kommatrennung.



*Use the configured SNMP-Read or Read/Write-Community for the query.*

An MIB for incorporating into management applications is available for downloading on the data sheet page of the WuT homepage at <http://www.wut.de>.

If you would like to use SNMP to change settings in the device (IP address, subnet mask, etc.), it is necessary to first use the SNMP manager to start a session on the device.

 *If you have assigned an administrator password, you must enter this in your management software as a „community string“!*

Entering the administrator password in the variable

```
wtWebGraphAnalogIn57641SessCntrlPassword
```

opens a session. By reading out the variable

## W&T

```
wtWebGraphAnalogIn57641SessCntrlConfigMode
```

you can check whether the session was successfully opened.

- 1 = Session opened, device in configuration mode.
- 0 = Opening of the session failed. Check whether the password was incorrectly entered if a password has been assigned.

After the session has been successfully opened, the variables defined in the private MIB can be used to make any desired configuration changes.

After the configuration is finished, the session is closed by writing the variable

```
wtWebGraphAnalogIn57641SessCntrlLogout
```

```
wtWebGraphAnalogIn57641SessCntrlLogout=
```

- 1 All changes are saved
- 2 Quit without saving

If no SNMP communication takes place during an open session for a period of 5 minutes or longer, the device unilaterally quits the session and no changes are saved.



*Opening an SNMP session has priority over an HTTP login. That means: A user with Config or Administrator rights loses his browser access as soon as an SNMP session is opened.*

The description for the individual SNMP variables, OIDs etc. can be found in the private MIB.

## 4 Java Applets - Auto-updating in the browser

Visualizing states in the browser based on pure HTTP or HTML allows only a snapshot. What is displayed is the status at the time the Web page was opened. The only way to see a state change is to reload the complete Web page.

A Java applet is implemented in the Web-IO Analog-In for displaying current states in the browser.

In order to enable the most flexible utilization, the Java applet invokes pre-defined Javascript functions which must be declared in the head of the HTML page.

### 4.1 Working with the Java applet

You incorporate the applet using the `<applet>` HTML tag, whereby the standard parameters *archive* and *code* are set as follows:

```
archive="A.jar"  
code="A.class"
```

The remaining parameters are set individually based on the application.

```
name="Analog"
```

The term *Analog* was randomly selected here and can be replaced by any other desired term. The only important thing is that when invoking the applet functions using JavaScript the same name is used.

```
codebase="IP-Adresse des Web-IO Analog-In"
```

If the Web page from which the applet is loaded is loaded directly from the Web-IO as *user.htm* or *home.htm*, you can skip the *codebase* parameter.

## W&T

`width="0"`      Angabe in Pixel  
`height="0"`     Angabe in Pixel

Since the applet does not contain a visual component, *width* and *height* should always be 0.

`mayscript`

This option allows the Java applet to use JavaScript code in the HTML document.

In addition, several other Web-IO-specific parameters can be set, each of which is inserted in its own `<param>` tag:

### **device**

Whole number value between 0 and 255. The *device* parameter is used for indexing when more than one Web-IO is operated on a single Web page.

If you are using only one Web-IO Analog-In, set the value to 0. For all additional devices incorporated into the Web page, the value is incremented by 1.

### **showerrors**

If errors occur when using the Java applet, this parameter can be used to specify whether an error message in the form of an alert window will be output.

For *showerrors* you can set *on* or *off* as *value*.

### **sensorpolling**

This parameter is used to specify when the applet is started whether the ports should be checked for their measure value at the interval set under *pollingrate*.

For *sensorpolling* you can set *on* or *off* as *value*.

### **pollingrate**

This parameter is used to specify (using *value*) at what interval (in ms) the ports should be updated.

Here is an example:

```
<applet name="Analog" archive="A.jar" code="A.class"
  codebase="http://192.168.0.5" width="0" height="0" mayscript>
  <param name="device" value="0">
  <param name="showerrors" value="off">
  <param name="sensorpolling" value="on">
  <param name="pollingrate" value="500">
</applet>
```



*Both the parameters and the values are case-sensitive.*

### 4.2 Using the applet with JavaScript

To be able to work with the applet, a corresponding JavaScript function must be declared in the header of the Web page.

```
function sensorChanged( iDevice, iSensor, iVal )
{ program code carried out when the measured value changes }
```

The above function is invoked by the applet when a change is detected on the measuring inputs. *iDevice* indicates on which Web-IO Analog-In a value changed. *iSensor* indicates which port (0 or 1) changed. The variable *iVal* indicates the actual measured value.



*Please note that the function name is case-sensitive.*

The following source text shows a short example for dynamic display of Port 0.

```
<html>
<head>
  <script language="JavaScript" type="text/javascript">
    <!--
    function sensorChanged( iDevice, iSensor, iVal )
    {   if (iSensor == 0 && iDevice == 0)
        { document.getElementById( 'port' + iSensor ).firstChild.data = iVal;
        }
    }
    //-->
  </script>
</head>
<body>
  <applet name="Analog" archive="A.jar" code="A.class"
    codebase="http://192.168.0.5" width="0" height="0">
    <param name="device" value="0">
    <param name="showerrors" value="off">
    <param name="sensorpolling" value="on">
    <param name="pollingrate" value="4">
  </applet>
  <p>current value port 0:</p>
  <p id="port0">0</p>
</body>
</html>
```



*When working with ports, note the following: If polling is activated, the associated JavaScript function must be declared in the HTML text so that there are no runtime errors.*

## W&T



*A more detailed example for use of the Java applet can be found on the Web page `app.htm`, which can be opened in the Web-IO.*

Open: `http://<ip-adresse>/app.htm`

## 5 Data Logger

The Web-IO Analog-In stores all them measured values in a fixed ring memory, so that they are still intact even after a power loss or after pressing the Reset button.



*The measuring data in the data logger are obtained through the user page of the device (Home -> User bzw. <http://xxx.xxx.xxx.xxx/user.htm>).*

Under *Config -> Device -> Data Logger -> Memory* you can clear the memory.

An interruption of the time line, such as resulting from a reset or a subsequent time server synchronization, is represented on the data logger page as a yellow line.

14.10.2003	Di	08:40	23,1
14.10.2003	Di	08:47	23,1
14.10.2003	Di	08:46	23,1
14.10.2003	Di	08:45	23,0
01.01.2002	Di	12:08	23,0
01.01.2002	Di	12:07	23,0
01.01.2002	Di	12:06	22,9
01.01.2002	Di	12:05	22,9
01.01.2002	Di	12:04	23,0

time line interruption:  
yellow marked line



*If alarm limits are set, measured values that are not within the valid range are highlighted in red.*

## 6 Appendix

### 6.1 Alternate IP address assignment

#### 6.1.1 Using DHCP-/BOOTP protocol

Many networks use DHCP (Dynamic Host Configuration Protocol) or BOOTP for centralized and dynamic assigning of the IP addresses. It makes no difference to the Web-IO devices which of the two protocols is used in any given case, since DHCP is simply a downward compatible extension of BOOTP. DHCP servers also make use of requests from BOOTP clients.

The following parameters can be assigned to the Web-IO Analog-In using these protocols:

- IP address
- Subnet mask
- Gateway address

It is not possible to configure any other parameters or lease time.

#### Functionality

To obtain an IP address, the unit sends a corresponding BOOTP request as a broadcast after each new start. The reply generated by the DHCP/BOOTP server contains the IP address as well as the subnet mask and gateway address. The device immediately stores this information in its non-volatile memory.

## W&T

Please consult your system administrator when starting up the device in DHCP/BOOTP networks. If the address is assigned using DHCP, you must also indicate that a reserved IP address is required. To integrate this into the respective address database, the administrator needs the Ethernet address of the device, which can be found on the housing sticker.

Once the necessary entries have been made, the device automatically retrieves the desired IP address after each reset. To ensure the Web-IO Analog-In can still be reached should the DHCP/BOOTP server be down, the previous IP address is retained if no reply is forthcoming.



*In DHCP environments the IP address to be assigned must be reserved by means of a fixed link to the Ethernet address of the device. Under Windows NT this is done in the DHCP Manager under menu item „Reservations“. Linux provides the file „dhcpd.conf“ for this purpose, where the corresponding entry must be made.*

### 6.1.2 ...using ARP command

The prerequisite is a PC located in the same network segment as the Web-IO Analog-In and which has TCP/IP protocol installed on it. Read off the MAC address for the device (e.g. EN=00C03D0012FF). Under Windows you first ping another network device and then use the command line indicated below to make a static entry in the ARP table of the computer:

## W&T

```
arp -s <IP-Adresse> <MAC-Adresse>
```

e.g. under Windows:

```
arp -s 172.0.0.10 00-C0-3D-00-12-FF
```

e.g. under SCO UNIX:

```
arp -s 172.0.0.10 00:C0:3D:00:12:FF
```

Then ping the device again (in our example ping 172.0.0.10). The IP address is now stored in the non-volatile memory.



*This method can only be used if no other IP address has already been assigned to the device, i.e. the entry is 0.0.0.0. To change an already existing IP address you must open the configuration menu from your browser.*

### 6.1.4 ...using RARP-Server (UNIX only)

Working with an RARP server activated under UNIX is based on entries in the configuration files, `/etc/ethers` and `/etc/hosts`. First expand `/etc/ethers` by one line by assigning the Ethernet address of the device to the desired IP address. In `/etc/hosts` the link is then established with an alias name. After you have connected the device in the network segment of the RARP server, you can use the network to assign the desired IP address to the device.

#### Example:

Your Web-IO Analog-In has MAC address EN=00C03D0012FF (sticker on the housing). You want to assign IP address 172.0.0.10 and alias WT\_1 to it.

Entry in the file `/etc/hosts`: 172.0.0.10 WT\_1

Entry in the file `/etc/ethers`: 00:C0:3D:00:12:FF WT\_1

If the RARP daemon is not yet activated, you must start it now using the command „`rarpd -a`“.

## 6.2 Example for creating your own Web pages

You can freely configure the standard display pages of the device (user.htm, home.htm, log.htm). Special control elements can be inserted into the page using tags. In the following you will find an example for creating the page „user.htm“.

Create an HTML page which must begin with the expression

```
<user.htm> (bzw. log.htm oder home.htm)
```

Then you enter the HTML code.

You can display the following parameters on your page:

```
<w&t_tags=m1>
```

displays the current measured value of the first port.

```
<w&t_tags=m2>
```

displays the current measured value of the second port.

```
<w&t_tags=time>
```

inserts the current time.

```
<w&t_tags=steps>
```

inserts a list box for selecting the time steps to be displayed.

```
<w&t_tags=ok_button>
```

inserts an „OK“ button for sending the selected parameters to the device.

## W&T

```
<w&t_tags=session>
```

inserts an invisible session control so that the user is not logged out from the device when leaving the page. The expression is only needed if you want to create your own button for sending. Insert this expression between *<form action>* and *</form>*.

Background color:

Background colors for the values shown in tables can be used for indicating the sensor state:

```
<w&t_tag=bc1>
```

describes a background color (BGColor) that varies with the alarm state of the first port. If there is a limit violation, this color is red. Otherwise the tag does not describe an explicit color. This tag is used for example to show limit violations in red in the log table.

```
<w&t_tag=bc2>
```

Background color for the second port.

```
<w&t_tag=location>
```

fills in the configured location settings.

```
<w&t_tag=contact>
```

fills in the configured contact settings.

```
<w&t_tags=sensorx>
```

inserts the name of sensor x into the page and contains a link for the complete sensor description.

```
<w&t_tags=device_name>
```

Inserts the assigned device name.

```
<w&t_tags=device_text>
```

Inserts the freely configurable descriptive text for the device.

```
<w&t_tags=reload_button>
```

inserts a „Reload“ button for reloading the current page.

## W&T

```
<w&t_tags=previous_button>
```

```
<w&t_tags=next_button>
```

inserts a button for moving ahead or back in the table.



*The „Previous“ button and the „Next“ button only have any meaning in the „log.htm“ file.*

```
<w&t_tags=logtable>
```

inserts a table with the current measurements. You can navigate this table only on the „log“ page using the „Next“ and „Previous“ buttons (see above). On both the other pages (user.htm, home.htm) only the current measured values can be displayed.

## W&T

Example for setting a background color in a table:

```
<tr>
  <td colspan="3" align="center">
    <table border="2">
      <tr>
        <th><w&t_tags=sensor1></th>
      </tr>
      <tr>
        <td <w&t_tags=bct><w&t_tags=ml> A</td>
      </tr>
    </table></td>
</tr>
```

The measured value is highlighted in red when there is a limit violation.

To specify the output format for the data, insert the following line into your document:

```
<form action="log.htm" method="POST" >
....
</form>
```

CSV output can be specified using the expression

```
<form action="logger.csv" method="POST" >
....
</form>
```



*Resetting the device to its factory defaults restores the original HTML pages.*

# W&T

## Example for user.htm:

```
<user.htm>
<html>
<head>
<title>Untitled Document</title>
<meta http-equiv="Content-Type" content="text/html; charset=iso-8859-1">
</head>


<body bgcolor="#FFFFFF" text="#000000">
<p>Web-IO Analog-In</p>
<p>Time: <w&t_tags=time></p>
<p><w&t_tags=sensor1>: <w&t_tags=m1></p>
<p>&nbsp;</p>

<form action="log.htm" method="POST">
  <p>Output data logger:</p>
  <p><w&t_tags=steps></p>
  <p><w&t_tags=ok_button></p>
</form>

<form action="logger.csv" method="POST">
  <p>Output CSV:</p>
  <p><w&t_tags=steps></p>
  <p><w&t_tags=ok_button></p>
</form>

<form action="user.htm" method="GET">
  <p><w&t_tags=reload_button></p>
</form>
</body>
</html>
```

This page is displayed by the Web-IO Analog-In in the Web browser as follows:



## W&T

### Example for log.htm:

```
<log.htm>
<html>
<head>
<title>Untitled Document</title>
<meta http-equiv="Content-Type" content="text/html; charset=iso-8859-1">
</head>


<body bgcolor="#FFFFFF" text="#000000">

<form action="log.htm" method="POST">
  <w&t_tags=previous_button>
</form>

<w&t_tags=logtable>

<form action="log.htm" method="POST">
  <w&t_tags=next_button>
</form>
</body>
</html>
```

This page is displayed by the Web-IO Analog-In in the Web browser as follows:



### 6.3 Firmware update

The operating software for the Web-IO Analog-In is being constantly enhanced. The following section describes how to upload the firmware when new versions become available.

- Where do I obtain the current firmware?
- Firmware update over the network under Windows

#### 6.3.1 Where do I obtain the current firmware?

The most up to date firmware version including the available update tools and a revision history are published on our Web pages under the following address: <http://www.wut.de>

Before downloading, first write down the 5-digit part number printed on the label of the Web-IO Analog-In. From the homepage you reach the product overview sorted by article numbers, from which you can get directly to the data sheet for the device. Follow the link to the current version of the firmware.

#### 6.3.2 Firmware update over the network under Windows

The prerequisite is a PC running under Windows 9x/NT/2000/XP with a network connection and activated TCP/IP stack. For the update process you will need two files which, as already described, are available for downloading at <http://www.wut.de>.

- the executable update tool for sending the firmware to the Web-IO Analog-In
- the file with the new firmware you want to load into the device

## W&T

No special preparation of the device is needed for the firmware update.

The *WuTility* used for the update recognizes all WuT devices located in its network and is for the most part self-explanatory. If you do have questions or if anything is unclear, please refer to the accompanying documentation or try our online help.



*Never intentionally interrupt the update process by disconnecting power or activating the Reset button. The Web-IO Analog-In will be inoperable following an incomplete firmware update.*

*Never mixes files having different version numbers in the file name. This will result in inoperability of the device.*

*The Web-IO Analog-In automatically recognizes when uploading of the new firmware is complete and performs an autonomous reset.*

## 6.3.3 LED indicators

- **Power-LED:** Indicates the presence of supply voltage. If the LED is not on, please check for proper connection of the power supply.
- **Status-LED:** Flashes whenever there is network activity. The Web-IO Analog-In is not receiving a link pulse from a hub or switch. Please check the cable or the hub/switch port.
- **Error-LED:** The Error LED uses various blink codes to indicate error conditions on the device or network port.

**1x blinking of the Error-LED** = Check network connection. The Web-IO Analog-In is not receiving a link pulse from a hub or switch. Please check the cable or the hub/switch port.

**2x or 3x blinking of the Error-LED** = Interrupt the power supply to perform a reset. If the error has not cleared, reset the device to its factory defaults. Since all the network settings will be reset, you should write down your network setting before performing the reset.

Config -> Session Control -> LogOut -> Restore Defaults

After a reset the device is restored to its factory defaults. Reconfigure your network settings.

- **Power-LED Status-LED Error-LED on**  
= Self-test error

The self-test performed after each reset of the device was not able to be carried out successfully - due for example to an incomplete update of the firmware. In this state the device is inoperable. Please return the device for repair.

## Auxiliary-LEDs (internal)

- **on error http://xxx.xxx.xxx.xxx/diag -LED:** Indicates internal configuration errors. For diagnostic information open page <http://xxx.xxx.xxx.xxx/diag> in the device.
- **system error:** Serious hardware error. Try restarting the device by interrupting turning power off and on. If the problem persists, return the unit for service.

**!** *If the device has no IP address or the address is 0/0/0/0, the LEDs „on error“ and „system error“ remain on after a reset or new start. The system error LED flashes 3x after a short time. The LEDs do not turn off until an IP address has been assigned.*



**6.4 Technical Data**

<b>Prod. No.: 57644</b>	
<b>Measurement unit</b>	
Voltage input:	2x 0..10V, 1M $\Omega$ m
Power supply:	12-24V AC / DC via terminal screw
Resolution:	2x Voltage input: 1,25mV
Measuring error:	max. 0,5% FSR (Full Scale Range 0..10V) TA = 0-60°C
Saving frequency:	1, 5, 15, 60 min.
Memory (832k):	min. 79 days, max. 17 years
Deviation of internal clock:	max. 4,32 min. / month
Data logging (request via Network and alarm trigger):	2/second
Saving in internal data logger:	1/minute
Galvanic isolation:	Input vs. Network: min. 500 Volt
Mail function:	Mail for sending alarm or reports
Supply voltage:	DC 12V (-5%) -34V (+5%)
Current consumption:	AC 9Veff (-5%) - 24Veff (+5%) AVG:185mA @ 12VDC, 90mA @ 24VDC
Power supply:	provided power supply or 12..24V AC/DC
Housing:	Plastic housing, 105x75x22mm
Weight:	approx. 200g
Storage temperature:	-40..+70°C
Operating ambient temperature:	0..+60°C
<b>AC Current Transducer 0..50A</b>	
Output signal:	0-5VDC or 0-10VDC (Default)
Frequency range:	30-6000Hz (all waveforms)
Response time:	400ms
Accuracy:	1% Full Scale
Supply voltage:	24VDC +/- 5%
Output load for voltage output:	10k $\Omega$ m min.
Isolation voltage:	5000V
Current consumption:	<30mA
Operating ambient temperature:	-20..+50°C

**6.5 Declaration of Conformity**

**Declaration of conformity  
according to paragraph 10.1 of directive 89/336/EWG**

Wiesemann & Theis GmbH hereby confirms that the products

<b>Web-IO 1x Thermometer</b>	<b>Model 57601</b>
<b>Web-IO 2x Thermometer</b>	<b>Model 57603</b>
<b>Web-IO 8x Thermometer</b>	<b>Model 57604</b>
<b>Web-Thermograph</b>	<b>Model 57605</b>
<b>Web-Thermo-Hygrograph</b>	<b>Model 57606</b>
<b>Web-IO Analog-In 0..20mA / 0..10V</b>	<b>Model 57641</b>
<b>Web-IO Analog-In 2x 0..20mA</b>	<b>Model 57642</b>
<b>Web-IO Analog-In 2x 0..10V</b>	<b>Model 57643</b>

fulfill the requirements of the directives / regulations specified below:

1. Emission according to
  - 1.1. EN 55022 Cl. B (1998) +A1 +A2
  - 1.2. EN 61000-3-2 (2000)
  - 1.3. EN 61000-3-3 (1995) + A1
2. Noise Immunity according to EN 61000-6-2 (2001):
  - 2.1. EN 61000-4-2 ESD
  - 2.2. EN 61000-4-3 Radiated Immunity
  - 2.3. EN 61000-4-4 Burst
  - 2.4. EN 61000-4-5 Surge
  - 2.5. EN 61000-4-6 Conducted Immunity
  - 2.6. EN 61000-4-8 H-Field
  - 2.7. EN 61000-4-11 Supply Voltage Dips and Interruptions
3. Product-specific Low-Voltage Directive for communications technology
  - 3.1. EN 60950 (2003)

Wuppertal, 03/08/2006

  
Klaus Meyer, EMC Representative

  
Dipl.-Ing. Rüdiger Theis, Managing Director



**Déclaration de conformité CE**  
**EC Declaration of conformity**  
**EG - Konformitätserklärung**



Le fabricant

The Manufacturer

**NANALEM K.K.**

Der Hersteller

2-1-2 Nakamachi, Machida  
Tokyo, 194-0021  
JAPAN

déclare que le matériel ci-dessous :  
hereby certifies that the appliance(s) indicated below :  
bestätigt, daß das nachfolgend bezeichnetes Gerät :

Capteurs de courant/tension  
Current /voltage transducers **Voir annexe**  
Strom-Spannungswandler

est conforme aux exigences des directives européennes suivantes :  
are in accordance with the requirements of the following EEC Directives :  
die folgenden Ansprüche der EG-Richtlinien erfüllt :

**89/336/CEE, CEM, EMC, EMV**  
**73/23/CEE, BT, LVD, NS**

Ce produit est conforme à la norme EN 61010 et EN 61326 et a été testé suivant cette norme.

The product is conform to the standard EN 61010 and EN 61326 and has been tested according to this standard.

Dieses Produkt ist konform der Norm EN 61010 und EN 61326 und wurde gemäss dieser Norm geprüft.

Machida, le 12.10.2005

Marc Laforet  
R&D Manager



