W&I connects

Interfaces for TCP/IP, Ethernet, RS-232, RS-485, USB, 20mA, glass and plastic fiber optic cable, http, SNMP, OPC, Modbus TCP, I/O digital, I/O analog, ISA, PCI



Firmware:

LAN modem, 10/100BT, 24V

Model 58620

Firmware packet (TCP/IP stack + modem interpreter) Current firmware

Date	Changes and comments	Revision
January 25,	Modem-Interpreter = 1.14	2.11
2011	Support for fragmented UDP/IP packets	ZIP download
	Optimizing of firmware upload in noisy environments	
	The newest included version of WuTility must be used for sending this firmware! The instructions for updating the individual firmware components are found in the associated manual.	

Older firmware

Date	Changes and comments	Revision
February 9,	Modem-Interpreter = 1.14	2.10
2010	Optimized handling when used with WuTility	on request
	Revised manual	
	Factory changed settings:	
	• Keep-Alive check = 5s	
	Control port deactivated	
	The instructions for updating the individual firmware components are found in the associated Manual.	



We are available to you in person:

Wiesemann & Theis GmbH

Porschestr. 12 42279 Wuppertal

Phone: +49 202/2680-110 (Mon.-Fri. 8 a.m. to 5 p.m.)

Fax: +49 202/2680-265

info@wut.de

© Wiesemann & Theis GmbH, subject to mistakes and changes: Since we can make mistakes, none of our statements should be applied without verification. Please let us know of any errors or misunderstandings you find so that we can become aware of and eliminate them.

Data Privacy