


Application for the Web-IO Digital:

Displaying climate data in camera images with the Web-Thermograph and Mobotix camera

Network cameras have become commonplace for building monitoring and property surveillance. The functional scope of today's IP cameras extends far beyond just displaying monitoring images.

Depending on the manufacturer and options, the cameras can for example receive text and status messages over the network and show them in the camera image. This functionality offers an ideal platform for displaying climate information for Web-Thermo-Hygrobarographs and all other Web Thermometers.



Using the example of a Mobotix camera and a Web-Thermo-Hygrobarograph, we will show you here how simply climate information can be integrated into camera images.



Step 1 - Configuring the Web-Thermo-Hygrobarograph


Preparations

You already have provided your Web-Thermograph

- with power
- [connected it to your network](#)
- assigned it an IP address - which with [WuTility](#) is no problem

Setting up a timer-controlled alarm

After logging in as Administrator, select from the menu tree *Config >> Device >> Alarms >> Alarm 1*



- Trigger :**
- Sensor 1: Temperature
 - Sensor 2: Humidity
 - Sensor 3: Air pressure
 - Timer <<<
 - Cold Start
 - Warm Start
 - Sensor lost

Temperature

Min : Grenzwert in °C.

Delay Time : Der Alarm wird erst ausgelöst, wenn für die Dauer dieser Zeit die Alarmbedingungen erfüllt sind (Zeit in Minuten).


Interval : Sending interval in minutes

Timer : Alarms will be activated only within predefined time

Minute	<input type="text" value="0,10,20,30,40,50"/> <<<	0-59
Hour	<input type="text" value="*"/> <<<	0-23 (0 is midnight)
Day_of_Month	<input type="text" value="*"/> <<<	1-31
Month	<input type="text" value="*"/> <<<	1-12
Weekday	<input type="text" value="*"/> <<<	0-6 (0 is sunday)

- Enable :**
- Mail enable
 - SNMP Trap enable
 - TCP Client enable <<<
 - Syslog Messages enable
 - FTP Client enable

These settings trigger the required alarm every 10 minutes. Now you just need to specify how the text message should appear to the Mobotix camera. To do this, select from the menu tree *Config >> Device >> Alarms >> Alarm 1 >> TCP*



IP Addr : Name oder IP-Adresse des TCP Servers im Folgenden
 <<<

Port : <<<

TCP Text : <<<

Alarm Clear Text : Diese Nachricht wird gesendet, wenn der Alarm

<<<

For *IP Addr* enter the IP address of the Mobotix camera, and for *Port* enter the port which is enabled with the Mobotix camera for network messages (see below). Under *TCP Text* enter the text message for later display in the camera. The placeholders *<T1>*, *<H1>* *<PN>* are replaced by the Web-Thermo-Hygrobarograph by the actual values. (Important: The last line must be finished with Return - new line)

Finally the settings must be saved in the Web-IO using *Logout >> Save*.


Step 2 - Configuring the Mobotix camera

Setting up the server port for network messages (RC)


Note: The Web and Basic models of the Mobotix camera do not support network messages

First log in to the Mobotix camera as Admin.


Then click on the button *Setup Menu*



In the following window select *Event Settings*.



Then scroll in the field *Network messages (RC)*.




Network Messages must be enabled. For *Port* enter the port to which the Web-Thermo-Hygrobarograph sends its message.

The other settings can be used as they appear in the upper illustration.


Finally, scroll down and click on the *Set* button. Then go back to the *Setup Menu* overview.

Setting up the text display

Here you select *Display and text settings*.



Here you can specify in which form the received network messages should be displayed.




In the Comments field you specify what should be displayed. This can be a fixed text such as a Web address - but it is also possible to position a placeholder for received network messages.

S3 stands here for 3 lines of message text.


Tip: A total of 60 lines are available. If as in the example shown you want a fixed text at upper left but the message itself at lower left, a corresponding number of line feeds must be inserted by pressing Return (here one line of text, 56x Return, three

lines of message).

Finally the settings must be applied by clicking on the *Set* button. Then return to the *Setup Menu* overview.




Now select General Event Settings.



Only if the item *Arming the Mobotix-Cam* is activated here will the Mobotix camera accept network messages.

Finally the settings must be applied by clicking on the *Set* button.

Then return to the *Admin menu*..



Scroll to the area *Configuration* and select *Save*.

Serial Interface

- [Setup](#) of serial interface, modem and weather station
- [Serial Terminal](#)
- [Signal State](#)

Configuration >>>

- [Store](#) current configuration into flash memory
- [Reset](#) configuration to factory defaults
- [Restore](#) last stored configuration from flash
- [Load](#) configuration from local computer
- [Save](#) current configuration to local computer
- [Show](#) current configuration ([raw version](#))
- [Edit](#) configuration file (for experts)
- [Manage](#) other cameras

System Update

- [Update System Software](#)

General Tasks

- [Reboot](#) the camera

Follow the instructions for permanently saving all settings

After no more than 10 minutes the temperature, relative humidity and barometric pressure should be displayed in the camera image.

Of course in the same way you can also display digital states (e.g. window open/closed) in a camera image. For this you need a Web-IO Digital instead of the Web-Thermo-Hygrobarograph. [See](#)

Do you not have a Web Thermometer but would like to try out this example?

No problem: We will be glad to send you the Web-Thermo-Hygrobarograph at no charge for 30 days. Simply fill out a sample ordering form, and we will ship the Web-Thermograph for testing on an open invoice. If you return the unit within 30 days, we will simply mark the invoice as paid.

[To sample orders](#) 



We are available to you in person:

Wiesemann & Theis GmbH
Porschestra. 12
42279 Wuppertal
Phone: +49 202/2680-110 (Mon.-Fri. 8 a.m. to 5 p.m.)
Fax: +49 202/2680-265
info@wut.de

© Wiesemann & Theis GmbH, subject to mistakes and changes: Since we can make mistakes, none of our statements should be applied without verification. Please let us know of any errors or misunderstandings you find so that we can become aware of and eliminate them.

[Data Privacy](#)